

CF65

BMW F650 (96)

Mounting kit			
ID	Description	Cat.no.	Pcs
1	Steel rod 10x165x30x30	-	1
2	Dural. cylinder – 17mm	84	2
3	Washer M10	804	2
4	Nut M10	961	2

Instructions

- 1.) Prepare both frames and fit them in lower part first.
- 2.) Put steel rod through the frame and tighten it using two cylinders, two washers and two nuts M10.
- 3.) Tighten upper part using original bolts.

