

CF108

Yamaha MT-09

Kit for Left Side			
ID	Description	Cat. No.	Pcs.
1	Frame		1
2	Bolt M10x120x1.25	895	1
3	Slider adapter d=40mm	317	1
4	Washer M10 flat	804	1
5	Dural. roller d=13mm	1127	1
6	Safety nut M10	810	1
7	Bolt M6x25	877	3
8	bolt M4x16	876	2
9	SL01- K		1
10	CapSL-Y		1
11	RDmoto Sticker		1

Kit for Right Side			
ID	Description	Cat. No.	Pcs.
1	Frame		1
2	Bolt M10x110x1.25	928	1
3	Slider adapter d=40mm	317	1
4	Washer M10 flat	804	1
5	Dural. roller d=5mm	168	1
6	Safety nut M10	810	1
7	Bolt M6x25	877	3
8	Bolt M4x16	876	2
9	SL01- K		1
10	CapSL-Y		1
11	Rdmoto Sticker		1
12	Rod 10x 300x30x30		1

We recommend using medium strenght thread glue.

Mounting Instructions (same for both sides):

- 1.) Remove the original bolt from upper part of the frame.
- 2.) Prepare the Slider adapter (ID.3), Bolt (ID.2) and Dural. roller (ID.5) depending on which side of motorcycle you are installing at this point.
- 3.) Attach the upper part with M10 (ID.2) Bolt.
- 4.) Remove the original bolt from the bottom part of frame.
- 5.) Now push through the Rod (ID.12), fit the rear of the frame and attach it using M10 (ID.4) washers and nuts (ID.6).
- 6.) Finally, tighten all assembly. As a last step, mount the slider using ID.7 bolts and the Cap with ID.8 bolts.



