

CS04KD

Suzuki V-Strom 650 2017-

Mounting kit left side:

ID	Description	Cat. No.	Pcs.
1	Left adapter CS04	X99	1
2	Bolt M8x45	820	1
3	Bolt M10x35x1,25	1040	1
4	Bolt M10x45x1,25	926	1
5	Washer M8	802	1
6	Roller d=20mm	1252	1
7	Washer M10	804	2
8	Roller d=9mm	1249	1
9	Stand end cap	X101	1
10	Roller d=9mm	1251	1
11	Roller d=3mm	1250	1
12	Original end cap rubber		

Mounting kit right side:

ID	Description	Cat. No.	Pcs.
1	Right adapter CS04	X100	1
2	Bolt M8x35	861	1
3	Bolt M10x35x1,25	1040	1
4	Washer M10	804	1
5	Washer M8	802	1
6	Roller d=9mm	1249	1
7	Roller d=9mm	1251	1
8	Spring	X93	1
9	Spring	X57	1

Mounting instructions left side:

1. First, fit the left and right adapters CS04 onto central stand as shown on attached photo.
2. Then, place it from the bottom side onto motorcycle frame and fix using M10 (ID.3) bolt, (ID.7) washer and (ID.10) roller. Finally, attach the (ID.9) end cap and using M8 (ID.2) bolt, M8 (ID.5) washer, (ID.11) roller and (ID.8) roller.
3. As a last step, attach the end cap rubber.

Mounting instructions right side:

1. Attach the assembly from bottom side onto the motorcycle frame and fix using M10 (ID.3) bolt, (ID.4) washer and (ID.7) roller. Then, fit the M8 (ID.2) bolt, M8 (ID.5) washer and (ID.6) roller.
2. Finally, fit the (ID.8 and ID.9) springs.

We recommend to begin with fitting the (ID.3) bolts on both sides.



When mounting, we recommend using medium strenght thread glue (blue color).