

CF73

VOGE 300AC 2021-

FITTING KIT			
ID	Description	Cat.No.	Pcs
1	Bolt M8x30mm	834	1
2	Steel bar 10x310x30x30mm	10x310x30x30	1
3	Nut M10-insurance	810	4
4	Washer M10-flat	804	4
5	Steel bar 10x165x30x30mm	10x165x30x30	1
6	Dural. roller l=10mm	106	1
7	Plastic cover	X37	2
8	Sticker RDMoto		2

Instruction :

- 1.) Support the engine before removing the original M10 bolts.
- 2.) Remove the original M10 screws from the motorcycle frame, see pictures.
- 3.) Insert the steel rod ID.2 in the upper part of the attachment and insert the rod ID.5 in the lower part.
- 4.) In the lower part, slide ID.6 duralumin rollers onto the rod from both sides.
- 5.) Place the left and right crash frames on the prepared steel bars.
- 6.) Tighten ID.3 nuts with ID.4 washers on both sides.
- 7.) At the point where the crash frames connect in front of the engine, tighten them with screw ID.1.
- 8.) Place the ID.8 plastic caps on the M10 nuts in the upper part of the motorcycle.

