

CF161

Brixton 500 Crossfire

Kit for left side:

ID.	Description	Cat.No	Pcs
1	Crash frame	CF161-L	1
2	Dural.roller l=5mm	16	1
3	Dural.roller l=10mm	108	1
4	Bolt M10x35x1,25mm	1044	1
5	Bolt M10x45x1,25mm	926	1
6	Bolt M10x55x1,25mm	915	1
7	Washer M10 – flat	804	1
8	Cover for the tube	X19	1

Kit for right side:

ID.	Description	Cat.No	Pcs
1	Crash frame	CF161-P	1
2	Dural.roller l=5mm	16	1
3	Dural.roller l=10mm	108	1
4	Bolt M10x40x1,25mm	941	1
5	Bolt M10x45x1,25mm	926	1
6	Bolt M10x55x1,25mm	915	1
7	Washer M10 – flat	804	1
8	Cover for the tube	X19	1

Mounting Instructions:

We recommend using medium strength thread glue during assembly.



Left side - lower attachment



Upper attachment = bolt
M10x35x1.25mm ID.4
+ duralumin roller
l=10mm ID.3

Lower attachment = if the main RDMoto stand is
mounted, the lower bolt is kept in the original
length of M10x35x1.25mm and only a duralumin
roller l=5mm ID.2 is inserted under the footrest
holder.

If the main stand is not mounted, the
M10x45x1.25mm ID.5 bolt is used.

Right side - lower attachment



Upper attachment = bolt
M10x45x1.25mm ID.5
+ duralumin roller
l=10mm ID.3

Lower attachment = bolt
M10x40x1.25mm ID.4 + duralumin
roller l=5mm ID.2.