

CF53

KTM 990 Adventure

Kit for the left side

No.	Description	Cat.no.	Pcs
1	Crash frame		1
2	stirrup	X78	1
3	nut M8	951	2
4	washer M8 - flat	802	4
5	screw M8x70mm	841	1
6	screw M8x40mm	828	1
7	dural roller d=12mm	130	1
8	plastic cover 25mm	X19	1
9	tape 3M		2
10	sticker RDmoto		1
11	washer M8 - spring	800	2

Kit for the right side

No.	Description	Cat.no.	Pcs
1	Crash frame		1
2	stirrup	X78	1
3	nut M8	951	2
4	washer M8 - flat	802	4
5	screw M8x70mm	841	1
6	screw M8x40mm	828	1
7	dural roller d=12mm	130	1
8	plastic cover 25mm	X19	1
9	tape 3M		2
10	sticker RDmoto		1
11	washer M8 - spring	800	2

Installation:

Make the installation of the crash bar according to the instruction on the below attached photos.

The installation of the crash bar for the left and right side is the same.

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).



plastic cover

bolt M8x40mm + washer M8
(flat) + duralumin cylinder
d=12mm

bolt M8x70mm + pad
M8 (flat)



Stirrup + 3M tape + 2x
washer M8 (flat) + 2x
washer(spring) + 2x
nut M8