

CF58

Yamaha MT07

Fitting kit for the left side			
ID	Description	Cat.no.	Pcs
1	AL insertion for protector	X122	1
2	Screw M12x130x1.25	1027	1
3	protector	PVPKN-0/16	1
4	Washer M10 flat	804	1
5	Dural. roller d=45mm	1303	1

Fitting kit for the right side			
ID	Description	Cat.no.	Pcs
1	AL insertion for protector	X122	1
2	Screw M12x130x1.25	1027	1
3	protector	PVPKN-0/16	1
4	Washer M10 flat	804	1
5	Dural. roller d=45mm	1303	1
6	Screw M10x40x1.25	941	1

We recommend to use glue on all threads (medium strong).

Instructions (for both sides):

- 1.) Remove original screw from upper part of frame.
- 2.) Prepare protector and screw.
- 3.) Attach upper part of frame using screw M12 (ID2), place the roller (ID5) between the drop frame and the engine frame.
- 4.) Remove original screw from lower part of frame.
- 5.) Attach lower part of frame using this original screw, but right screw M10x40x1.25(ID4)
- 6.) Tighten both screws.



