

CF113

Lower Honda CRF 1000 Africa Twin Sport Adventure(manual) '18-

Mounting Kit:

ID	Description	Cat. No.	Pc
1	Roller d=25, hole diam 8,5	1257	2
2	Bolt M8x70	841	2
3	Washer M8 flat	802	2
4	Silentblock	X34	1
5	Nut M8	813	1
6	RD Sticker		2

Follow the instructions on pictures below.

Note: We recommend using thread glue during installation (blue color).

First, take off the lower engine guard. Then, unscrew original bolt M8 from the frame. Use the ID.2 bolt and equip it with washer and frame from the right side of the motorcycle. Now, place the ID.1=25mm roller and ID.4 silentblock underneath the frame on its right side, loosen the bolt in rear part, mount the frame and tighten both bolts. Now do the same on the left side, unscrew the original bolt from frame, place the ID.1 roller, crash frame and ID.3 washer onto the ID.2 bolt, unscrew the original bolt in rear part, mount the crash frame and tighten. Finally, you can place back the engine guards.

