

CF105

Honda X-ADV 750_2017-

Kit for left side			
ID	Description	Cat. No.	Pcs.
1	Frame	CF104	1
2	Bolt M8x90	1054	1
3	Bolt M8x50	837	1
4	Dural. roller d=31mm	1264	1
5	Dural. roller d=19mm	1265	1
6	Bolt M8x40	828	1
7	Washer M8 flat	800	2
8	Plastic cover	X5	3
9	RDmoto Sticker		1
10	Bolt M8(5)x60	1055	1
11	Frame XADV		1

Kit for right side			
ID	Description	Cat. No.	Pcs.
1	Frame	CF104	1
2	Bolt M8x90	1054	1
3	Bolt M8x50	837	1
4	Dural. roller d=31mm	1264	1
5	Dural. roller d=19mm	1265	1
6	Bolt M8x40	828	1
7	Washer M8 flat	800	2
8	Plastic cover	X5	3
9	RDmoto Sticker		1
10	Bolt M8(5)x60	1055	1
11	Frame XADV		1

We recommend using medium strenght thread glue.

Mounting Instructions (same for both sides):

- 1.) Unscrew the original bolts from your motorcycle.
- 2.) Prepare the crash frame and all necessary bolts.
- 3.) Begin with the ID.10 bolt to attach top part of the ID.11 frame and connect it by the bottom part to the top part of ID.1 frame.
- 4.) Attach the top part of ID.1 frame to upper part of ID.11 frame using the M8 ID.2 bolt, then proceed with middle part and M8 ID.3 bolt and M8 ID.7 washer (insert the ID.4 roller between motorcycle and crash frame) and finally the rear part using M8 ID.6 bolt and ID.7 washer (insert ID.5 roller between crash and motorcycle frame).
- 5.) Mount the other side using the same procedure.
- 6.) Finally, tighten all screws and place the ID.9 RDmoto Stickers.



