

CF117-SLDM

Yamaha V-Max 2009-

Kit for Left Side

ID	Description	Cat. No.	Pcs.
1	Frame	CF117	1
2	Plastic cover M10	X4	2
3	Bolt M10x100x1,25	892	1
4	Dural. roller d=46mm	1295	1
5	Bolt M10x70x1,25	898	1
6	Dural. roller d=15mm	1294	1
7	Bolt M10x55	1002	1
8	Dural. roller d=20mm	10	1
9	SLD adapter	537/B	1
10	Bolt M6x20	1024	2
11	Washer M6	1023	2
12	Slider		1

Kit for Right Side

ID	Description	Cat. No.	Pcs.
1	Frame CF117		1
2	Plastic cover M10	X4	2
3	Bolt M10x85x1,25	934	1
4	Dural. roller d=11mm	461	1
5	Bolt M10x70x1,25	898	1
6	Dural. roller d=15mm	1294	1
7	Bolt M10x55	1002	1
8	Dural. roller d=20mm	10	1
9	SLD adapter	537/B	1
10	Bolt M6x20	1024	2
11	Washer M6	1023	2
12	Slider		1

We recommend using medium strenght thread glue during assembly.

Installation Instructions:

- 1.) First, unscrew the original upper M10 bolt and another M10 bolt in the middle part.
- 2.) Then use M10 ID.5 bolt and ID.6 dural roller to mount the upper part of frame (dont tighten any bolts yet).
- 3.) Continue by using M10 ID.3 bolt and dural. roller ID.4 to mount the bottom part.
- 4.) Tighten both bolts at this point.
- 5.) Mount the ID.9 SLD adapter and ID.8 roller onto the M10 ID.7 bolt and fit this assembly into thread on frame.
- 6.) Finally, attach ID.12 slider by M8 ID.10 bolt and M8 ID.11 washer.
- 7.) Use the same procedure on the right side.





Bolt M10 ID.5 +
Roller ID.6 ++
Cover M10 ID.2

Bolt M10 ID.7 +
Adapter SLD ID.9 +
Roller ID.8 + slider
ID.12 + 2x Bolt M8
ID.10 + Washer M8
ID.11

Bolt M10 ID.3 +
Roller ID.4 + Cover
M10 ID.2

