

CF126

Triumph Tiger Explorer 2011-2015 Triumph Tiger Explorer XC 2011-2015

Kit for Left Side			
ID	Description	Cat.No	Pcs
1	Frame	CF126-L	1
2	Bolt M8x30mm	834	2
3	Dural. sleeve length=6mm	453	1
4	Flat washer M8	802	2
5			
6			

Kit for Right Side			
ID	Description	Cat.No	Pcs
1	Frame	CF126-P	1
2	Bolt M8x30mm	834	1
3	Bolt M8x35mm	861	1
4	Flat washer M8	802	2
5	Dural. sleeve l=13mm	1100	1
6	Dural. sleeve l=13mm	464	1

We recommend using medium strenght thread glue during assembly.

Instructions:

- 1.) Remove 3 original bolts on the left side of the motorcycle.
- 2.) Take the bolt ID 2 and washer ID 4, slide it into the front upper part of the frame.
Then take another bolt ID 2 and washer ID 4 and slide it into the middle bottom part of the frame.
- 3.) Attach to the motor and mount. Also thread the dural. sleeve ID 3 on the bolt in the middle lower part of the frame. Use the original bolt to attach the crash frame to the rear. For safety reasons, you can use medium strength thread glue.
- 4.) Remove 2 original bolts on the right side of the motorcycle and the original rear long bolt, which slide out of the motorcycle frame.
- 5.) Take the bolt ID 2 and washer ID 4, slide it into the front upper part of the frame.
Then take the bolt ID 3 and washer ID 4 and slide it into the middle bottom part of the frame.
- 6.) Attach to the motor and mount. Also thread the dural. sleeve ID 6 on the bolt in the middle lower part of the frame. To attach the crash frame to the rear, use the original bolt and dural. sleeve ID 5. For safety reasons, you can use medium strength thread glue.
- 7.) Finally, tighten all the bolts.

