

CF79KD

Yamaha MT07

Fitting kit for the left side			
ID	Description	Cat.no.	Pcs
1	Crash frame		1
2	Screw M12x130x1.25	1027	1
3	Slider	SL01	1
4	SL adaptér	1137	1
5	Screw M6x25	877	3
6	Screw M4x16	876	2
7	Cover Black	CAPSL-K	1
8	Dural. roller d=45mm	1303	1

Fitting kit for the right side			
ID	Description	Cat.no.	Pcs
1	Crash frame		1
2	Screw M12x130x1.25	1027	1
3	Slider	SL01	1
4	SL adapter	1137	1
5	Screw M6x25	877	3
6	Screw M4x16	876	2
7	Screw M10x40x1.25	941	1
8	Dural. roller d=45mm	1303	1
9	Cover black	CAPSL-K	1
10	Washer M10 flat	804	1

We recommend to use glue on all threads (medium strong).

Instructions (for both sides):

- 1.) Remove original screw from upper part of frame.
- 2.) Prepare protector and screw.
- 3.) Attach the upper part with adapter and duralumin with roller (ID8), screw M12 (ID2)
- 4.) Remove original screw from lower part of frame.
- 5.) Attach lower part of frame using this original screw, but right screw M10x40x1.25(ID4)
- 6.) Tighten both screws.
- 7.) Attach the SL adapters using the M6 screws(ID.5) and then the cover, using screws M4(ID.6).



