

CF102

Honda CB 300 R_2018-

Kit for Left Side			
ID	Description	Cat. No.	Pcs.
1	Frame	CF102	1
2	Dural. roller d=36mm	1239	1
3	Safety nut M10	810	3
4	Washer M10 flat	804	3
5	Rod 10x285x30x30		1
6	Rod 10x120x30x30		1
7	Rod 10x230x30x30		1

Kit for Right Side			
ID	Description	Cat. No.	Pcs.
1	Frame	CF102	1
2	Dural. roller d=36mm	1239	1
3	Safety nut M10	810	3
4	Washer M10 flat	804	3
5	Dural. roller d=47mm	48	1
6	RDmoto Stickers	L+P	2

We recommend using medium strenght thread glue during assembly.

Instructions (same for both sides):

- 1.) Take off the original bolts and replace them with rods, as shown on attached pictures.
- 2.) Take the ID.2 roller and fit it onto the rod in front part from both sides of the frame.
- 3.) Starting with left side, fit the ID.4 M10 washers and M10 ID.4 nuts onto all three rods in the frame.
- 4.) Then, fit the frame from right side and insert the ID.5 roller between the motorcycle and crash frame in the rear part.
- 5.) Then, take the M10 ID.4 washers, attach them using M10 ID.3 nuts and fit them onto the remaining three rods.
- 6.) Finally, tighten the nuts on both sides and make sure that all fits.



