

CF109

Honda CB 1000 R Neo Sport Café

Kit for left side			
ID	Description	Cat. No.	Pcs.
1	AL insertion for protector	X122	1
2	Bolt M12x125x1.25	952	1
3	Protector	PVPKN-0/16	1
4	Washer M10 flat	804	1
5	Safety nut M10	810	1
6	Plastic cover M12	X60	1
7	RDmoto sticker		1
8	Nut cap M10	X35	1

Kit for right side			
ID	Description	Cat. No.	Pcs.
1	AL insertion for protector	X122	1
2	Bolt M12x125x1.25	952	1
3	Protector	PVPKN-0/16	1
4	Washer M10 flat	804	1
5	Safety nut M10	810	1
6	Plastic cover M12	X60	1
7	RDmoto sticker		1
8	Nut cap M10	X35	1
9	Rod 400x10x30x30		1

We recommend using medium strenght thread glue during assembly.

Mounting instructions (same for both sides):

- 1.) Unscrew the original bolt from upper part of the frame.**
- 2.) Prepare the protector with its bolt.
- 3.) Attach the upper part of ID.1 Frame using the ID.2 M12 bolt, but do not tighten yet.
- 4.) In the rear part, take the ID.8 Rod and push it through. Now attach the crash frame onto the rod with ID.4 washer and Id.5 M10 nut.
- 5.) Use the same instructions for installing the left side.
- 6.) Finally, tighten all bolts and fit the caps (ID.6).



ID9 + ID4 + ID5
+ ID8

ID2 + ID3 + ID6