

CF29

Honda XLV 650 Transalp 2000-2007

Kit for the left side

No.	Description	Cat.no.	Pcs
1	Crash bar		1
2	Steel adapter with thread M8	X18	1
3	Bolt M6x30mm	863	1
4	Bolt M8x50mm	837	2
5	Pad M8 (spring)	800	2
6	Pad M6 (plane)	987	1
7	Bolt M8x110mm	844	1
8	Nut M8 (safety)	809	1
9	Cover on head of bolt	X5	2
10	Tape 3M		1
11	Advertising sticker RDmoto		1
12	Washer M8 flat	802	1

Kit for the right side

No.	Description	Cat.no.	Pcs
1	Crash bar		1
2	Steel adapter with thread M8	X18	1
3	Bolt M6x30mm	863	2
4	Bolt M8x50mm	837	2
5	Pad M8 (spring)	800	2
6	Pad M6 (plane)	987	1
7	Cover on head of bolt	X5	2
8	Tape 3M		1
9	Advertising sticker RDmoto		1
10	Nut M6	948	1
11	Washer M6	947	2
12	Washer M8 flat	802	1

Installation:

Make the installation of the crash bar according to the instruction on the below attached photos.

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

The right side:



two bolts M8x50mm +
two pads (spring) +
two covers on head of
bolts + steel adapter

for connecting of the
left and right crash
bar with frame of
the motorcycle; bolt
M8x110mm + two
pads (plane) + nut
M8 (safety)

for connecting of the
crash bar with frame
of the motorcycle;
bolt M6x30mm +
pad (plane)

For connecting both
frames under the
light use bolt M6x30
and 2xwashers and
nut M6

The left side:



for connecting of the crash bar with frame of the motorcycle; bolt M6x30mm + pad (plane)

for connecting of the left and right crash bar with frame of the motorcycle (viz the right side)

two bolts M8x50mm + two pads (spring) + two coves on head of bolts + steel adapter