

CF87

Kawasaki Z650_2017-

Kit for left side			
ID	Description	Cat. No.	Pcs.
1	Frame	CF87	1
2	Roller d=16mm	1268	1
3	Safety nut M10	810	2
4	Washer M10 flat	804	2
5	PVPKN 0/10		1
6	Bolt M10x200	889	1
7	Plastic cover M10	X35	1
8	Plastic cover M10	X4	1
9	Dural. roller d=70mm	DV7	1
10	Rod 10x370x30x30		1
11	RDmoto sticker		1

Kit for right side			
ID	Description	Cat. No.	Pcs.
1	Frame	CF87	1
2	Roller d=10mm	1267	1
3	Safety nut M10	810	2
4	Washer M10 flat	804	2
5	PVPKN 0/10		1
6	Bolt M10x200	889	1
7	Plastic cover M10	X35	1
8	Plastic cover M10	X4	1
9	Dural. roller d=15mm	DV8	1
10	Dural. roller d=15mm	144	1
11	RDmoto sticker		1

We recommend using medium strenght thread glue.

Mounting instructions (same for both sides):

- 1.) Take off the original bolt in front left part of the motorcycle.
- 2.) Put M10 ID.4 washer, ID.5 protector and ID.1 frame onto the M10 ID.6 bolt and roller ID.9(for right side ID.9 and ID.10)
- 3.) This assembly mount into the motorcycle frame using the M10 ID.3 nut (start from rear part).
- 4.) Then, place the ID.2 roller under the frame (in rear part) and put in the ID.10 rod, onto which you will place the M10 ID.4 washer with M10 ID.3 nut.
- 5.) Follow the same procedure on the other side and finally, tighten all bolts.
- 6.) As a last step, place the ID.7 and ID.8 covers with ID.11 stickers.



