

CF101

KTM 390 Duke_2018-

Kit for Left Side			
ID	Description	Cat. No.	Pcs.
1	Frame	CF101	1
2	Dural. roller d=30mm	1252	1
3	Safety Nut M10	810	1
4	Washer M10 flat	804	1
5	RDmoto stickers		1
6	Bolt M8x45	964	2
7	Dural. roller d=13mm	464	2
8	Washer Flat M8	802	2
9	Dural. roller d=5,6mm	214	1
10	Rod 10x240x30x30		1

Kit for Right Side			
ID	Description	Cat. No.	Pcs.
1	Frame	CF101	1
2	Dural. roller d=30mm	1252	1
3	Safety nut M10	810	1
4	Washer M10 flat	804	1
5	RDmoto Stickers		1
6	Bolt M8x45	964	2
7	Dural. roller d=13mm	464	2
8	Washer M8 Flat	802	3
9	Bolt M8x40	828	1
10	Dural. roller d=16mm	252	1

We recommend using medium strenght thread glue.

Mounting Instructions (same for both sides):

- 1.) Unscrew the original bolt on bottom left side and replace it with ID.10 Rod, onto which you should put the ID.2 roller, then frame and finally ID.4 M10 washer with ID.3 M10 nut.
- 2.) Then, remove two bolts in top part and one in rear part as shown on attached pictures.
- 3.) Instead of the two bolts in top part, put the ID.7 rollers between motorcycle frame and crash frame and attach it using M8 ID.8 washers and M8 ID.6 bolts.
- 4.) At the rear part, replace original roller with ID.9 roller and frame, then tighten this assembly with the original bolt.
- 5.) Use the same steps for mounting the right side, only now at the rear part replace original bolt with ID.10 roller and M8 ID.9 bolt.
- 6.) As a last step, equally tighten and check all nuts and bolts at both sides.



