



# SHAD

**BCN**

## HONDA GB 350 S '25-

**TOP MASTER  
H0GB35ST****1** 263806 x1 →  
263807 x1 ←**2** 261502 x2  
Ø16 Ø9 x 42**3** 303045 x4  
Ø8**4** 303027 x4  
Ø8**5** 304174 x4  
M8x80 DIN 7380**6** 260564 x2  
Ø16 Ø9 x 33

### WARNING!

**GB** Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned. Check tightness every 4 months.

**E** No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado. Repasar apriete cada 4 meses.

**D** Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist. Alle 4 Monate Drehmoment überprüfen.

**I** Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato. Controllare il serraggio delle viti ogni 4 mesi.

**F** Ne pas serrer les vis avant d'être sûr que le KIT soit correctement positionné et ajusté. Vérifier le serrage des vis tous les 4 mois.

**ATTENTION:** For a full equip assembly, mount the Top master before the Cafe Racer

