

KTM13N

KTM 1290/1390 SuperDuke

Left side:

ID.	Description	Cat.No.	Pcs
1	Steel washer	X1/10	1
2	Dural.adapter	775	1
3	Dural.roller l=59,5mm	DV-4/10	1
4	Bolt M10x85mm	981	1
5	Dural.roller l=46mm	1228	1
6	Dural.roller l=55mm	1130	1
7	Bolt M10x80mm	852	1
8	Bolt M10x90mm	880	1
9	Plast.cover	X4	2

Right side:

ID.	Description	Cat.No.	Pcs
1	Steel washer	X1/10	1
2	Dural.adapter	776	1
3	Dural.roller l=39,5mm	DV-2/10	1
4	Bolt M10x65mm	943	1
5	Dural.roller l=46mm	1228	1
6	Dural.roller l=55mm	1130	1
7	Bolt M10x80mm	852	1
8	Bolt M10x90mm	880	1
9	Plast.cover	X4	2





Assembly:

1. Remove the original bolts on the left side.
2. Take the duralumin adapter for the left side ID.2 and insert the bolts M10x80mm ID.7 (upper mount) and M10x90mm ID.8 (lower mount), from the back of the adapter, slide duralumin rollers with a length of 46mm ID.5 (upper mount) and a length of 55mm (lower mount) onto the bolts, mount this entire assembly on the motorcycle frame.
3. Put plastic caps ID.9 on the bolt heads.
4. Take the crash protector and insert a duralumin roller with a length of 59.5mm ID.3 into it from the back.
5. Put a steel washer ID.1 into the protector and mount it on the duralumin adapter with a bolt M10x85mm ID.4.
6. The assembly on the right side is identical except for the crash protector attachment. Here, use a duralumin roller with a length of 39.5mm ID.3 and a bolt M10x65mm ID.4.

Using the KTM13N mounting kit you can mount all types of our sliders with the markings PH, PHV, SL and SD.

If you have any problems or questions, please contact us by email: info@rdmoto.eu.
Thank you for purchasing our product. Team RDMoto

Warning - we recommend using medium-strength (blue) adhesive on the threads of all screws.

Illustrative photo of mounting points.

Right side:



Left side:

