



**Install note for
CRBPLKIT6-6B/G/Y**




This bearing consists of two halves. The half with the oil galley, and two holes is installed in the top half of crankcase

**Install note for
CRBPLKIT6-6B/G/Y**




This bearing consists of two halves. The half with the oil galley, and two holes is installed in the top half of crankcase

**Install note for
CRBPLKIT6-6B/G/Y**




This bearing consists of two halves. The half with the oil galley, and two holes is installed in the top half of crankcase

**Install note for
CRBPLKIT6-6B/G/Y**




This bearing consists of two halves. The half with the oil galley, and two holes is installed in the top half of crankcase

**Install note for
CRBPLKIT6-6B/G/Y**




This bearing consists of two halves. The half with the oil galley, and two holes is installed in the top half of crankcase

**Install note for
CRBPLKIT6-6B/G/Y**




This bearing consists of two halves. The half with the oil galley, and two holes is installed in the top half of crankcase

**Install note for
CRBPLKIT6-6B/G/Y**




This bearing consists of two halves. The half with the oil galley, and two holes is installed in the top half of crankcase

**Install note for
CRBPLKIT6-6B/G/Y**




This bearing consists of two halves. The half with the oil galley, and two holes is installed in the top half of crankcase

**Install note for
CRBPLKIT6-6B/G/Y**




This bearing consists of two halves. The half with the oil galley, and two holes is installed in the top half of crankcase

**Install note for
CRBPLKIT6-6B/G/Y**




This bearing consists of two halves. The half with the oil galley, and two holes is installed in the top half of crankcase

**Install note for
CRBPLKIT6-6B/G/Y**



This bearing consists of two halves. The half with the oil galley, and two holes is installed in the top half of crankcase

**Install note for
CRBPLKIT6-6B/G/Y**



This bearing consists of two halves. The half with the oil galley, and two holes is installed in the top half of crankcase